

## Dörrskylt Påminnelse Batteri Manual



## Innehållsförteckning / Table of Contents

|  |   |
|--|---|
| Dörrskylt Påminnelse Batteri Manual .....      | 1 |
| Introduktion .....                             | 2 |
| Passar den på mitt dörrhandtag? .....          | 2 |
| Användning.....                                | 3 |
| English version.....                           | 4 |
| Door Handle Reminder Battery User Manual ..... | 4 |
| Introduction.....                              | 5 |
| Will it fit on my door handle?.....            | 5 |
| Using the product.....                         | 6 |

# Introduktion


\*\*\*

Denna skylt placeras som en påminnelse på handtaget på ytterdörrens insida. Detta minskar risken för att du glömmet ta med dig batteriet till din elcykel mm när du lämnar hemmet, kontoret mm.

Viktig information:


- Varning kvävningsrisk! Den här produkten innehåller eller består av smådelar vilket kan utgöra en kvävningsrisk om småbarn och husdjur. Håll produkten (och alla dess delar) utom räckhåll för småbarn och husdjur

## Passar den på mitt dörrhandtag?

|   |   |
|---|---|
|  | <ul style="list-style-type: none"><li>• Skyltens hållare är 24 mm i diameter</li><li>• Kontrollera att ditt dörrhandtags diameter ej är större än detta</li></ul> |
|---|---|

2

## Användning



- Placera skylten på handtaget på ytterdörrens insida som en påminnelse att ta med batteriet till din elcykel etc

\*\*\*

|                 |                                   |
|-----------------|-----------------------------------|
| Material:       | ABS-plast                         |
| Mått LxBxH:     | 48x28x66 mm                       |
| Vikt:           | 10 Gram                           |
| Detta ingår:    | 1 st Dörrskylt Påminnelse Batteri |
| Artikelnummer:  | 005-003-002-002                   |
| HS-nummer:      | 3926 10 00 00                     |
| Manual Version: | V1                                |

English version

## Door Handle Reminder Battery User Manual




## Introduction

This sign is placed on the door handle on the inside of your front door. It will reduce the risk of you forgetting the battery for your electric bicycle etc. at home, in the office, etc.


Important information:

- Warning Choking Hazard! This product contains or consists of small parts, which may be a choking hazard for small children and pets. Keep this product (and all of its parts) out of reach of children and pets

### Will it fit on my door handle?

|   |   |
|---|---|
|  | <ul style="list-style-type: none"><li>• The holder of the sign has a diameter of 24 mm</li><li>• Check that the diameter of your door handle is no larger than this</li></ul> |
|---|---|

## Using the product



- Place the sign on the door handle on the inside of your front door as a reminder to bring the battery for your electric bicycle etc. with you

\*\*\*

|                     |                                |
|---------------------|--------------------------------|
| Materials:          | ABS-plastic                    |
| Measurements LxWxH: | 48x28x66 mm                    |
| Wheight:            | 10 Gram                        |
| Included:           | 1 Door Handle Reminder Battery |
| SKU:                | 005-003-002-002                |
| HS-number:          | 3926 10 00 00                  |
| Manual Version:     | V1                             |